

Operations & Maintenance

For Anodized Finishes:

- 1) Clean as needed with a non-acidic or alkaline cleaning product.
- 2) Light scratches may be removed with a light abrasive.

For Painted Finishes:

- 1) Use a soft brush or cloth with a common cleaner/water to remove dirt and follow with a water rinse. Avoid using abrasive cleaners and materials.
- 2) Use mineral spirits to remove substances such as glue, caulking, etc. and rinse with water after.
- 3) Mono-Kote Fireproofing Compound should easily brush off.
- 4) If common cleaners or mineral spirits do not work for any sealant or similar substance that gets on the frame and an alcohol-based solvent is needed, test on a small area first as this could possibly damage the paint.

For Glass Surfaces:

- 1) Use common cleaning solutions such as Windex or similar products.

For Hardware Surfaces:

- 1) Wipe with a mild soap and water mixture.
- 2) Use water to rinse off detergent left behind.
- 3) Disinfect using products approved by the Centers for Disease Control & Prevention (CDC).
- 4) Per CDC guidelines, disinfectant should be applied using a cloth and left to air dry. Do not spray or immerse the hardware in disinfectant at any point during the cleaning process.